
## Sightmaster 3 - Assembly Instructions


Note: to avoid any accidental loss of components, please do not dispose of packaging until the sign is fully assembled.



The cartons will contain a water-fill base and a poster frame. Insert the poster frame into the holes in the water fill base.



Resting the poster frame on the packaging, use the fixings shown to attach the water-fill base to the poster frame. Ensure the fixings are fully tightened for correct sign performance.



Use the lever tool to open the poster frame sides. Insert the poster behind the poster cover before closing the frame sides. Remove fill cap and use a hose to fill the base with water until overflowing. Alternatively sand can be poured in using a funnel.

